

---

# **USER MANUAL**

## **SMART WATCH**


Shenzhen Ployer Electronics Co., Ltd.

---

## NOTICE

- ◆ **MAINTAINANCE:** Do not use or store the watch in dusty, hot, cold, electric, chemical, or magnetic areas. Do not drop, shake or knock the watch. Rough handling can break the watch. Please do not disassemble the watch or change the case personally, as it will void your warranty.
- ◆ **SECURITY:** Please turn off the watch in aircraft and follow any restrictions. Wireless devices can cause interference in aircraft. Never play the watch while driving!
- ◆ **UPDATE:** Due to different marketing period, regional disparities or such reasons, we may, change or modify some functions which could be different from the content in this page, please refer to real product received.

## Appearance and External Buttons



- (1) Power
- (2) Camera
- (3) Microphone
- (4) Screen


- (5) Speaker
- (6) Charging pins
- (7) Heart rate sensor
- (8) SIM cover

---

## Get Ready

### SIM Card Installation


The watch only supports NANO-SIM card, please remove SIM cover at back case, and install NANO-SIM card.



Standard SIM



Micro-SIM



Nano-SIM

*Tips: Availability and network speed depend on user's 4G/3G/2G network, and fees apply.*

### Recharging

Before using the watch, please recharge the device for over 2 hours. Please use standard charging socket and match pins on watch and socket.

---


## Basic Operations

### POWER ON / OFF

Long press Power button to turn on the watch, and it goes to watch face. Please recharge it if watch cannot be turned on. When the device is ON, long press Power button and choose Power off to turn off the device.


### User Wizard

When the device is firstly turned on, it goes to User Wizard. You can choose default language and set weight, height, walk target and gender.




---

Scan QR code to install **WiiWatch 2** App on mobile phone.



You can also search **WiiWatch 2** in *AppStore* (iOS edition) or in *Google Play* (Android edition).

After **WiiWatch 2** App installed in mobile phone, you can open the Bluetooth of the phone and watch.

Tap BACK button  to scan the QR on screen to connect.

---

## Watch Face

At watch face, you can slide to enter primary interfaces, including:

- Slide leftwards: **App list**
- Slide rightwards: **Notification center**
- Slide upwards: **Pedometer**
- Slide downwards: **Status bar**

Long press watch face, slide leftwards or rightwards to view all available watch faces, and tap one watch face to set it as default.

At watch face, press Power button to turn screen off.

## Primary and Secondary Interfaces



Primary interfaces includes App list, Notification center, Pedometer, and Status bar. At all primary interfaces, press Power button to turn off screen and switch to standby mode. If you enter any function of App list, it goes to secondary interfaces or sub-interfaces. At secondary or sub-interfaces, slide rightwards on screen

---

to go back to previous interface.

## Menu

At any interface, long press Power button to select menu, including: screen mode (Square Screen or Full Screen), Power Off, Reboot, Power Save, Recent Task or Cancel.



Square Screen Mode: convenient to view edge of Apps, but some images and letters will be smaller.



Full Screen Mode: images and letters are larger but sometimes edge of Apps can not be seen.





---

## Notification center

At watch face, side rightwards to enter interface of Notification center. Here you can see message from mobile phone or this device. Slide leftwards to exit Notification center.

## Pedometer





At watch face, slide upwards to enter interface of Pedometer. Here you can slide leftwards or rightwards to view Pedometer history, today's step, distance, and consumed calories. Slide downwards to exit Pedometer.



---

## Status bar



At watch face, side downwards to enter interface of Status bar. Here you can slide leftwards or rightwards to view Time & Date & Battery info, Quick Switch Panel, Clean-up, Music & Sound Control, etc. Slide upwards to exit Status bar.



---

## App List


At watch face, side leftwards to enter interface of App list. Here you can slide upwards or downwards to view Contacts, Phone, Messaging, Settings, Browser, Downloads, Calendar, Clock, Camera, Gallery, Music, Sound Recorder, File Manager, Heart Rate Monitor, Fitness, Weather, Voice Search, Play Store, Maps, Assistant, Barometer, App Store, and other manually installed Apps by user.





## Contacts

Tap one contact person's name to call or send message.


Tap  to add new contact, synchronous contacts or delete contacts.



## Phone



Tap number to enter telephone number, and then tap



to call, or tap  to delete number. Slide leftwards to view call logs.



## Messaging

Tap  to write new message. Tap  to edit quick text, set SMS Service Center, and other general settings.



## **Settings**

You can set Sound, Display, App List Style, Connect, Gesture, Power saving, Languages & input, and Date & time, and reset equipment, uninstall application, view About watch, etc.



## **Browser**

You can search or type URL, or tap favorite URLs for fast visit.



## **Downloads**

You can view all downloaded files.



## **Calendar**

Slide upwards or downwards to switch month.




## **Clock**

You can slide leftwards or rightwards to view or set Alarm, Global clock, Timer and Stopwatch.



## **Camera**

Tap  to take a photo.

Tap  to start video recording, tap red icon  to stop video recording.

Tap thumbnail to view saved photo or video.



## **Music**

You can slide leftwards or rightwards to view Artists, Albums, Songs, Playlists.



## **Sound Recorder**

Click the MIC icon to start recording, type Done to stop recording, and then choose to Discard or Save the recording files.



## **File Manager**

Firstly you can view available and used spaces, and then tap the screen to view detailed file folders. Long press a file folder or file to view and operate more options.



## **Heart Rate Monitor**

After several seconds' checking, the screen will display your heart rate BPM.



## **Fitness**

You can slide upwards or downwards to switch sports

---

mode, including Outdoor Run, Outdoor Walk, Indoor Run, Ride Bike, Play Basketball, Play Football, Play Ping-Pong, Play Badminton, and Rope Skipping. Slide leftwards to see record of sports. Slide rightwards to exit Fitness.



### **Weather**

Tap the icon to update weather.

*Tips: This function needs network.*



### **Voice Search**

Enter Voice Search and say keywords, the device will search keywords by Google.

For new search, say “OK Google” or tap MIC icon.

*Tips: This function needs network.*

Slide rightwards or press Power button to exit Voice Search.





## Play Store

Enter Play Store and log in Google account, and search Apps from Play Store.

*Notice: This function needs to log in Google account and network. Due to Screen size and resolution limitation, some 3<sup>rd</sup> part Apps from Play Store might not work well on this watch.*



## Maps

Enter Maps and sign in Google account to use the location service. Please turn on GPS and DATA (or Wi-Fi) switches from Quick Switch Panel to experience better service.



## Assistant

Tap Connect Phone and use **WiiWatch 2** APP on mobile phone to scan the QR code. After you connect the watch

---

with mobile phone, you can use remote capture, music control on the phone, and send files to phone, and find the device.



### **Barometer**

With built-in Barometer sensor, you can view current place's relative height and atmospheric pressure.



### **App Store**

Here you can download most popular Apps like Facebook, Twitter, WhatsApp and Youtube.

Remarks: other manually installed Apps will be displayed on App list interface.

---

## FAQ


### **Q: Why the watch cannot be turned on?**

**A:** The most likely reason is that the battery is drained. Often, it's a simple problem that is easily fixed after recharging. If still not working, ask qualified seller for repairing.

### **Q: Why are some apps not working?**

**A:** Some functions, like Play Store, Voice Search, need user to sign in Google account before using. Some other functions need network before using, for example, weather and Voice search. Please ask qualified seller for further help if you come across trouble.

### **Q: If the watch is with an unknown system language, how to change it into another language?**

**A:** At watch face, side leftwards to enter interface of App list. Slide upwards to find Settings icon  and enter,



then slide upwards to find language setting icon and enter, then you can see the first selection is Languages. Tap Languages and tap icon + to add a new language.


Long press the new language name and move it to top in order to set it as default language.

### **Q: How to connect the watch with mobile phone?**

**A:** Please do following steps.

(1) Install **WiiWatch 2** App on mobile phone.



You can scan following QR code to download and install the App, or search **WiiWatch 2** in *AppStore* (iOS edition) or in *Google Play* (Android edition) and install.



---

(2) Open the Bluetooth of the phone and watch.  
(3) On watch, enter App List, enter Assistant, tap Connect Phone and use mobile phone's **WiiWatch 2** APP to scan the QR code.  
Now, you can see watch and mobile phone is connected.

### **Q: How to restore the factory default setting?**

**A:** enter App List, enter Settings  , enter Reset equipment  , choose the last selection Factory data reset, tap RESET WATCH, and tap ERASE EVERYTHING. Then the device will be restored to factory default setting, and it will automatically restart and enter User Wizard.